


# 1. CONTROLS AND CONNECTIONS



## OPTIONAL ACCESSORIES

- |  |  |
|--|--|
| CTN520: CTCSS (tone squelch) unit                                | CMC150: Mobile charger<br>(for CNB150, CNB151 and CNB153)    |
| CNB150: Compact rechargeable battery pack<br>(7.2 V, 400 mAh)    | CMB111: Mobile bracket                                       |
| CNB150: Rechargeable battery pack<br>(7.2 V, 700 mAh)            | CLC520: Soft case<br>(used with CNB151 or CBT151)            |
| CNB152: High-power rechargeable battery pack<br>(12 V, 600 mAh)  | CLC521: Long-sized soft case<br>(used with CNB152 or CNB153) |
| CNB153: Long-life rechargeable battery pack<br>(7.2 V, 1200 mAh) | CBT151: Battery tray (for 6 "AA"-size batteries)             |
| CWC150: AC charger (for CNB150, CNB151 and<br>CNB153)            | CMP111: Microphone/speaker                                   |
| CWC151: AC charger (for CNB152)                                  | CMP112: Compact microphone/speaker                           |
| CSA150: Desk-top charger (Rapid charger)                         | CHP111: Headset with PTT button                              |
| CAW150: Mobile power cable                                       | CMP113: Tiepin microphone                                    |
|  | CAW151: Base station power cable                             |
|  | CAX02: Bottom cap  |